



*Between these points make trail 6" wider than standard. Distance usually ranges from 3' to 4' on each side of deepest point on turn*

*On trails closely following contours at slight inturns make tread 6" wider than standard and build up higher obstruction than on straight away sections of dirt or rock to prevent cross cutting.*

*Augment inslope and out side rail.*

