

Showing use of rock wall to prevent cross cutting at turns of switch backs. Use only where rock of substantial sizes are handy.



Cross section 10' ahead of turn showing use of dirt rail or cut 18* to 24* deep and rocks on outer embankment to prevent cross cutting on switch back