

*Provide pack clearance in easiest possible way. Half-tunnel effect may be used to advantage under certain conditions*

*Start backslope 24" above trail tread.*

*Leave bench in place if land so breaks.*

*Stones piled on outer edge.*

*30" to 36" on slopes over 16.5%*

*Don't make treads wider to get pack clearance. The width shown intends that pack clearance be provided by excavating the bank starting at a point approximately 2 Ft. above tread.*